



# Premier Rod Technical

## The Product

- The Premier range of stair rods are available for either a runner carpet or fully fitted and in three diameters for runners and two diameters for fully fitted, see facing page for details.
- The Premier range are made to measure, see below for measuring guidelines.

## Premier Stair Rod For Carpet Runner.

- For 12mm dia. rods we recommend that you add 10cm to the width of your carpet and use this measurement to give you the tip to tip length of the stair rod, for 16mm dia. 12.5mm over and for 19mm dia. add 15cm over.




Standard

14mm clearance



High Lift

17mm clearance




5cm



Standard

15mm clearance



Standard


18mm clearance

- If you have either a very deep or thin carpet please call for advise.

ANY QUESTIONS  
Please call 0410304727 For friendly expert advice.

## Premier Rod For Fully Fitted Carpet.

- We recommend that you leave a 2.5 to 5cm gap between the stringboard and the tip of the rod at both sides of the staircase.



2.5cm-5cm

## Prepare Hinge Brackets For fitting

- The brackets for runner carpets are hinged and consist of a bottom and top section and cannot be mixed with the top or bottom of other brackets. To fit the brackets the top and bottom must be separated to allow access to the screw holes. This requires little effort and is accomplished by removing the dome head screw and placing your thumbs on the hinge part of the bracket and first two fingers on the inside of the top and bottom and gently ease open the bracket. This will loosen the hinge and allow you to slide them apart.

## Fitting Rods To Stair.

- Both runner and fully fitted brackets are supplied with number 6 screws and you must drill a pilot hole before fixing the brackets to the stair. For softwood create a 2.5mm pilot hole and for hardwood create a 3mm hole. A clearance hole of 4mm should be drilled to accommodate the screw shank. Remember to set your power drill on a low torque setting to avoid breaking the screws. With the hinged bracket separated fit the bottom half to the stair and put the rod in place then re fit the top half of the bracket by sliding the two half together, finally close with the dome head screw. For fully fitted carpets the supplied bracket sits on top of the rod and screws fix it through the carpet.

## Care and Maintenance

- We recommend using a damp cloth to keep the rods clean, any household cleaners used to clean the wood and paint work of the staircase should be applied to the cloth and not directly onto the surface of the stair, as over spray can cause a speckled tarnish on the rods. If any liquids are inadvertently spilt on the stair rods they should be cleaned immediately with a damp cloth and dried with a clean cloth.